





## LETTER FROM THE CEO

Dear Valued Customer,

Congratulations on purchasing your **SF-475 Accessory Kit**. You will find that it significantly increases the versatility of your **SF-475 SteamMax™ Garment Plus**, by transforming it from a garment steamer into a powerful steam cleaner. Use the natural power of steam on tiles, linoleum, metal, porcelain, and most any other surface in your home as a fresh and chemical-free cleaning alternative. No longer will you need multiple appliances for cleaning and ironing; with this accessory kit your **SteamMax™ Garment Plus** will become the practical all-in-one machine you've been waiting for.

**Top Innovations, Inc.** takes pride in providing excellent quality products, affordable prices, and outstanding customer support. We invite you to visit our website at:

[www.topinnovations.com](http://www.topinnovations.com)

On this website you will find additional information about many other exciting Steam Fast products that are available, helpful tips on ways in which you can utilize your **SF-475 Accessory Kit**, and other useful information to assist you in maximizing the power of steam! Also, feel free to call 1-800-711-6617 ext. 102/130 with any questions or concerns you may have. Our customer support team is available to assist you and to answer any of your questions about this exciting new product.

Enjoy your **SF-475 Accessory Kit**!

A handwritten signature in cursive script, appearing to read "Benny Lee".

Benny Lee  
Chairman and CEO  
Top Innovations, Inc.




## IMPORTANT SAFETY GUIDELINES



**WARNING:** To reduce the risk of fire, electrical shock, or injury, basic safety precautions should always be followed when using an electrical appliance. Refer to the SF-475 manual for further details on electrical safety.


### READ ALL INSTRUCTIONS BEFORE USING YOUR STEAMER

**IMPORTANT:** Before using this accessory kit with your SteamMax™ Garment Plus, refer to the **Important Safety Guidelines** section of the SF-475 SteamMax™ Garment Plus manual and familiarize yourself with all safety precautions listed there to avoid misuse and injury.

1. Accessories included in this kit are meant to be used only with SF-475 SteamMax™ Garment Plus. Attempting to use them with any other cleaning appliances may result in damage to accessories and appliance.
2. Use accessories in this kit only for their intended purposes as described in this manual.
3.  **These accessories are not toys.** Close supervision is required when being used near children, pets, and plants. DO NOT allow to be used by children.
4. DO NOT attempt to attach any of these accessories to SteamMax™ Garment Plus while unit is emitting steam. Doing so may result in burns and other injury.
5. Accessories included in this kit may become hot during use. To avoid injury, DO NOT touch nozzles or attachments while SteamMax™ Garment Plus is in use.
6. Use caution when cleaning certain types of surface areas:
  - Use Terry Cloth Cover attachment on sealed floor surfaces to create a shine. DO NOT use on unsealed wood products and surfaces.
  - DO NOT use hot steam on cold glass surfaces; doing so may cause glass to break.
  - DO NOT use these accessories to clean soft plastics
  - Always test a small area when cleaning carpets, draperies, upholstery, or other fabric surfaces.
  - Using these accessories on wallpaper or self-adhesive vinyl will remove the material. DO NOT use on these types of surfaces unless you wish to achieve this result.

**FOR HOUSEHOLD USE ONLY  
SAVE THESE INSTRUCTIONS**

The following accessories and attachments are included in the SF-475 Accessory Kit. Carefully inspect packaging material as some parts are shipped inside Styrofoam packaging. To obtain possible missing parts, refer to the **Customer Support** section on page 5 of this manual.



- 1.) Steam Cleaning Hose
- 2.) Steam Jet Nozzle
- 3.) Scrub Pad
- 4.) Assorted Utility Brushes
- 5.) Triangle Brush
- 6.) Brass Utility Brush
- 7.) Terry Cloth Cover
- 8.) Floor Brush
- 9.) Squeegee
- 10.) Extension Wands



### WARNING

Attachments will become hot while unit is in use. Allow nozzle to cool before attempting to change attachments. **DO NOT attempt to change attachments while unit is still emitting steam.**



## PRODUCT INFORMATION

1.) **Steam Cleaning Hose**

Attaches to Hose Base on the SF-475 SteamMax™ Garment Plus and serves as the delivery system for hot, penetrating steam.

2.) **Steam Jet Nozzle**

Emits a concentrated jet of steam for tough cleaning tasks.

3.) **Scrub Pad**

Designed to assist you in cleaning kitchen counters, sinks, and more.

4.) **Assorted Utility Brushes**

Attach to Steam Jet Nozzle. Used when cleaning ceramic, metal, plastic, and fiberglass surfaces. Also used for removing stains from carpet. Five different types and sizes provide versatility for most cleaning needs.

5.) **Triangle Brush**

Assists you in cleaning hard-to-reach corners and other areas.

6.) **Brass Utility Brush**

Designed to aid in removing tough grease and grime from outdoor grills and oven racks.

7.) **Terry Cloth Cover**

Attaches to Floor Brush. Designed to safely clean sealed hardwood and tile floors.

8.) **Floor Brush**

Designed for cleaning and removing odors from carpets and floor surfaces. Can also be used on draperies and upholstery.

9.) **Squeegee**

Cleans glass surfaces such as patio doors, mirrors, windows, and more.

10.) **Extension Wands**

Attach to increase effective reach of steamer. Access hard-to-reach areas such as ceiling fixtures, draperies, and vents. Use in conjunction with Floor Brush to make cleaning and sanitizing floors easier.

### **CUSTOMER SUPPORT**

For problems with your steamer, please refer to the Troubleshooting Guide located on page 13 of the SF-475 manual. Additional inquiries should be directed to our Customer Support services at 1-800-711-6617 ext. 102/130 or e-mailed to [customerservice@topinnovations.com](mailto:customerservice@topinnovations.com). Should there be any missing or defective parts or accessories, contact Customer Support. In most cases, it is not necessary to return the entire unit. We can ship most parts directly to your door.

**To ensure prompt and accurate service, call for a Return Authorization number before returning any unit to Top Innovations. Failure to obtain a Return Authorization number will cause a delay in warranty or out-of-warranty service requests.**

### 1.) Attach Steam Cleaning Hose

1. Screw Hose onto the threaded Hose Base by turning fitting on end of Hose clockwise (FIGURE 1).
2. Hand-tighten only. Do not over-tighten.



FIGURE 1

### 2.) Attach Appropriate Accessory

Select accessory appropriate to the cleaning task at hand. Install accessory by depressing lock/release button located on handle and sliding accessory into position so that rectangular hole in tool slides over lock/release button (FIGURE 2). When accessory is properly installed, lock/release button will click into position. To disconnect an accessory, depress lock/release button on handle and slide accessory over button.



FIGURE 2

**NOTE:** When attaching a Utility Brush, align groove on Steam Jet Nozzle with raised nub of Utility Brush attachment.

### 3.) Begin Steaming

Once desired accessory is attached, proceed with normal filling and startup procedures for the SteamMax™ Garment Plus as outlined in the SF-475 instruction manual. When this is complete, you are ready to steam.

Push down on steam control button on top of handle for a burst of steam. For a constant flow of steam, slide steam control forward while steam button is depressed. Direct steam nozzle towards surface you wish to clean (FIGURE 3). Using a slight back-and-forth motion will enhance cleaning process when dealing with tough dirt, grease, and grime.




FIGURE 3



## WARRANTY INFORMATION

### ONE YEAR LIMITED WARRANTY

(If outside USA, additional shipping charges may apply)

Top Innovations, Inc. warrants this product to be free from defects in material and workmanship for a period of one (1) year from the date of purchase. This warranty does not cover damage caused by misuse, negligence, use by improper current or voltage, use contrary to operating instructions or disassembly, repair or alteration by any person other than Top Innovations, Inc. Warranty Service Department.

Top Innovations, Inc. will repair or replace, at its option. This warranty gives you specific legal rights and may have other rights, which may vary from state to state.

Performance of any obligation under this warranty may be obtained by:

1. Call (800) 711-6617 for Return Authorization Number before returning for repair
2. Include copy of purchase receipt
3. Include your name, address, telephone number, and Return Authorization Number on returned package

Please send product postage prepaid to:

TOP INNOVATIONS, INC.  
WARRANTY SERVICE DEPARTMENT  
400 NW PLATTE VALLEY DR.  
RIVERSIDE, MO 64150

After 1 year limited warranty has expired, you will be advised of the cost of repair before any servicing is done unless you enclose a note indicating that you would like us to proceed with repairs.

If you have any questions about coverage under this warranty, you may contact warranty service department by telephone at (800) 711-6617 ext. 102 / 130 or e-mail [customerservice@topinnovations.com](mailto:customerservice@topinnovations.com)



**Top Innovations, Inc.**

400 NW Platte Valley Dr.

Riverside, MO 64150

Tel: (800) 711-6617

[www.topinnovations.com](http://www.topinnovations.com)

[sales@topinnovations.com](mailto:sales@topinnovations.com)

**PRINTED IN CHINA**

V030714